



Husqvarna Attachments

Flail mower 547 11 54-01, ARFM5120v3,
547 11 54-02, ARFM5120v2

SV	Bruksanvisning	2-4
DA	Brugsanvisning	5-7
NO	Bruksanvisning	8-10
FI	Käyttöohje	11-13
DE	Bedienungsanweisung	14-16
FR	Manuel d'utilisation	17-19
NL	Gebruiksaanwijzing	20-22
SL	Navodila za uporabo	23-25
EN	Operator's manual	26-28
ES	Manual de usuario	29-31
PT	Manual do utilizador	32-34
IT	Manuale dell'operatore	35-37

Flail mower 547 11 54-01, ARFM5120v3, 547 11 54-02, ARFM5120v2

Intended use

This attachment is used together with a Husqvarna ride on mower to shred grass and weed very short. The attachment can cut rough surfaces that are not flat and has holes. All other use is incorrect.


Flail mower 547 11 54-01, ARFM5120v3 uses Y-blades that are used to shred grass.

Flail mower 547 11 54-02, ARFM5120v2 uses hammer-blades that are used to shred small and medium sized material of wood.

The manufacturer is not liable for damage caused by incorrect use.



Look out for ejecting objects and ricochets.



Keep bystanders away.



Monitor the directions of the blades and the number of revolutions shown.

Symbols on the attachment



WARNING: Be careful and use the product correctly. This product can cause serious injury or death to the operator or others.



Read the operator's manual carefully and make sure that you understand the instructions before you use this attachment.



Warning: risk of being pulled in by the blades.



Rotating parts. Keep your hands away from rotating parts.



Warning: rotating parts. Keep your feet away from rotating parts.



Warning: risk of crush and/or cut injuries.



Do not carry passengers on the product or the attachment.



Make sure that all moving parts have stopped before you do maintenance or examine the attachment.



Lubrication.



Attach the product to the lifting points. Only use approved lifting equipment.



The product agrees with the applicable EC directives.



This product conforms to applicable UK regulations.



Use personal protective equipment (PPE).



Husqvarna Service Information



Husqvarna Service Information

Model: [REDACTED]

Product number: [REDACTED]

1. Husqvarna model name
2. Husqvarna product number code (PNC)

Safety instructions for operation



WARNING: Read the warning instructions that follow before you start and use the attachment.



WARNING: Read the operator's manual of the product and make sure that you understand the instructions on the product before you start the attachment

- Always be careful and use your common sense. Avoid all situations which you consider to be beyond your capability. If you feel uncertainty about the operating procedures after you read the operator's manual, consult an expert before you continue.
- Use appropriate personal protective equipment during operation and maintenance.
- Learn how to use the attachment and its controls safely and learn how to stop the product quickly.

Learn to recognize the safety decals.

Safety decals can be found on the attachment and in this manual. Refer to *Symbols on the attachment on page 26*. If a safety decal on the attachment is damaged or missing, replace the safety decal.

- Do not let children or other persons not approved for operation of the attachment to use or do servicing on it. Local laws may regulate the age of the user.
- Do not keep passengers on the attachment.
- Do not use an attachment with safety devices that are damaged or do not operate correctly. Replace the safety devices if necessary.
- Do not use the attachment if persons, especially children, or animals, are within 50 m of the product.
- Always disengage the PTO button, apply the parking brake and stop the engine on the product before attaching the attachment. Make sure that the product and the attachment are stable.



WARNING: Be careful when attaching the attachment to the product, risk of crush injury. Use protective gloves.

- Examine the work area and remove all loose objects.
- Do a check of the safety devices before you operate the attachment.
- Do a test of all the functions of the attachment before you operate the attachment.
- Do not let the product stay unsupervised with the engine on. Always disengage the PTO button, apply the parking brake and stop the engine before you let the product stay unsupervised.
- Do not use the attachment if it is damaged or does not operate correctly.
- Do not overload the attachment capacity by operating the attachment at too fast a rate.
- Adjust the speed of the attachment based on the type and height of the material that is to be shredded.
- Operate the attachment at the correct RPM to avoid damage or excessive vibrations. Refer to the Appendix.
- Stop and examine the attachment if you operate the product across or into an object. If it is necessary, make repairs before you start.
- If the attachment starts to vibrate more than usual, stop the engine and examine the cause immediately.

Safety instructions for maintenance



WARNING: Read the warning instructions that follow before you do maintenance on the attachment.


- Only do the maintenance described in this operator's manual. More extensive work must be carried out by an authorized servicing dealer.



WARNING: Unauthorized modifications and/or accessories may lead to serious injury or death to the user or others. Under no circumstances may the design of the attachment be modified without the permission of the manufacturer. Always use original spare parts. Your warranty may not cover damage or liability caused by the use of non-authorized accessories or spare parts.

- The maintenance procedures described in this operator's manual must be done regularly. Refer to the Appendix.
- Disengage the PTO button, apply the parking brake and stop the engine on the product before you do maintenance on the attachment. Make sure that the product and the attachment are stable.

- Use the wheel safety locks to prevent accidental movement during maintenance and storage.



- Make sure that all moving parts have stopped before you examine the attachment.
- Do a check of the safety devices regularly. If the safety devices are missing or damaged, speak to your authorized servicing dealer.
- Do not make modifications on safety devices.
- Make sure that all nuts and bolts are tightened correctly and that the attachment is in good condition.
- Regularly examine and adjust the bolts on the blades of the attachment.
- Replace the belts when they are worn or damaged. Refer to the Appendix. Use the belt type XPA 925.
- Keep the attachment clean to make sure that you can clearly read signs and stickers.
- Use compressed air to clean the attachment.



CAUTION: Use protective glasses when cleaning with compressed air.


- Lubricate the attachment each 5 operating hours. Refer to Lubrication overview in the Appendix.
- Do a check of the tension of the belt each 5 operating hours. Refer to the Appendix.

To replace the oil in the gearbox

Replace the oil in the gearbox at a 500 hour interval.

Note: Replace the oil when the gearbox is hot.

There are 2 alternatives for how to drain the oil from the gearbox.



1. To drain the oil with an oil pump, do this procedure:
 - a) Remove the drain plug (A).
 - b) Use an oil pump to drain the oil through the drain plug.
2. To drain the oil manually, do this procedure:
 - a) Put a container below the gearbox.
 - b) Loosen the screw (B) and let the oil run out into the container.
 - c) Tighten the screw.
3. Fill the gearbox through the drain plug with new oil until oil comes out of the oil drain plug (approximately 0.5 l).

Note: Recommended oil type: VANGUARD AKRO 75W90

4. Tighten the cap carefully.